## wipe-on, spray or brush means as desired. Remove all old release toulene or ketones and recoating as described above. RELEASE. oven cure is necessary at 300 degrees F for 30 minutes after the mold surface has reached the 300 degrees F temperature. Recoating over worn areas is done by solvent cleaning the surface with 0-15 minutes should be allowed for solvent release. before applying 100 may be applied to clean surfaces by

After application, 100. Metal tools

9

Then an

ALL No. 100 may be removed completely by RELEASE-ALI

10 Mold Stripper.

agents

A MULTIPLE CYCLE RELEASE AGENT THAT DOES NOT TRANSFER



P.O. Box 3387 25512 East Base Line San Bernardino, California 92404

CONTENTS

BOE-C6-0202366